
TRANSPARENT ROUTER BASE/ TEMPLATE GUIDE

This unit will provide your router with an exactly centered template guide and, at the same time, allow you to see your work. For maximum utility, attach the Transparent Router Base to the bottom of your router housing after removing the router's standard opaque base. If there is insufficient flat surface on the bottom of the router's housing, you can attach it directly to the bottom of the router's original base plate. This will ensure that the Template Guide is centered, but reduce visibility somewhat.

To install the Transparent Router Base, first insert the brass index pin in the router collet and tighten. Next, apply the special double stick tape to the bottom of the router housing (or its base plate) and slip the Transparent Base over the index pin. Press the Transparent Base down firmly onto the tape. Remove the index pin from the collet; install a 1/4" router bit* and the Base is ready for use.

Note: A 1/4" Spiral Down-cut Bit, which produces optimum results for template routing, is available from our catalog. Ask for details.